



# QUICK START

## UNIGATE INVERTER


(1I - 2I - 1I BIG - 2I BIG)




## UNIGATE 2PM - 4PM



## UNIGATE 24V



## UNIGATE BR (36V)



**FULL MANUAL**  
(Rev. 11)  
&  
**SAFETY**  
**INFORMATION**



**SEA S.p.A.**  
Zona Industriale Sant' Atto - 64100 - Teramo - ITALY  
Telephone: + 39 0861 588341 - Fax: + 39 0861 588344  
[www.seateam.com](http://www.seateam.com)  
[seacom@seateam.com](mailto:seacom@seateam.com)


**THE UNIGATE REQUIRES THE PROGRAMMING OF THE WORKING TIMES (CHAPTER 13);**

IT IS NOT POSSIBLE TO START THE OPERATOR CORRECTLY WITHOUT FIRST PROGRAMMING THE CONTROL UNIT!


## «UNILOGIC» MAIN MODULE - COMPONENTS



**WARNING: CONNECT ALL DEVICES WHEN THE CONTROL UNIT IS SWITCHED-OFF**




● AUTOMATIC RECOGNITION OF THE N.C. INPUTS NOT IN USE - NO JUMPERS REQUIRED ON THE N.C. CONTACTS




\* ALL THE 24V INPUTS SUPPORT A MAXIMUM LOAD OF 1A REFERRED TO THE SUM OF THE LOADS OF ALL 24V ACCESSORIES CONNECTED, INCLUDING THE ABSORPTION OF THE RECEIVER ON BOARD (30 mA)

## UNIGATE INVERTER - «FV» MODULE


### CONNECTIONS ON «FV» MODULE



MOTOR  
CONNECTOR  
AND DRY  
CONTACT RELAY



INVERTER  
POWER  
SUPPLY  
230V/115VAC



USB  
CONNECTOR  
TO  
«UNILOGIC»



➔ COMPONENTS ALSO VALID FOR «FV-BIG» MODULE




DO NOT CONNECT THE CAPACITORS!





IT IS MANDATORY TO CONNECT THE GROUND CABLE ON THE «PE» INPUT

## UNIGATE 2PM / 4PM - «2PM» MODULE



### CONNECTIONS ON «2PM» MODULE



POWER SUPPLY  
CONNECTOR





MOTOR 1 and MOTOR 2  
CONNECTORS




USB CONNECTOR  
TO «UNILOGIC»

## UNIGATE 24V - «24V» MODULE


### CONNECTIONS ON «24V» MODULE



POWER SUPPLY  
CONNECTOR





MOTOR 1 and MOTOR 2  
CONNECTORS



USB CONNECTOR  
TO «UNILOGIC»

## UNIGATE BR - «BR» MODULE

### CONNECTIONS ON «BR» MODULE



IT IS MANDATORY TO CONNECT THE GROUND CABLE ON THE «PE» INPUT

## QUICK START

- 1 MAKE ALL THE CONNECTIONS WHEN THE CONTROL UNIT IS SWITCHED-OFF: ACCESSORIES (**CHAP. 1**), MOTORS (**CHAP. 2 - 5**), POWER SUPPLY (**CHAP. 6 - 10**)
- 2 DO NOT JUMPER THE N.C. CONTACTS (**AUTOMATIC DETECTION OF THE N.C. CONTACTS NOT IN USE**)
- 3 POWER ON THE CONTROL UNIT AND CHECK THE CORRECT STATUS OF THE INPUTS (**CHAP. 11**)
 

00111110  
11111111
- 4 OPTIONAL - SET UP THE «START» COMMAND ON THE TRANSMITTER (**CHAPTER 12**)
- 5 SET A PAUSE TIME TO OPERATE IN «AUTOMATIC» LOGIC, OTHERWISE THE LOGIC WILL BE «SEMI-AUTOMATIC» (**AUTOMATIC RECLOSING DISABLED**)
 

7  
PAUSE  
TIME
- 6 CHOOSE THE MOTOR TYPE ON MENU 3 (**SEE THE MENU TABLE**)
 

3  
MOTOR
- 7 MOVE THE OPERATOR USING THE MENUS
 

192  
MOVE  
GATE 1

OR

193  
MOVE  
GATE 2


AND IF THE GATE CLOSES BY PRESSING UP AND IF THE GATE OPENS BY PRESSING DOWN THE MOTORS RUN CORRECTLY, OTHERWISE SWAP THE MOTORS CABLES
- 8 START THE WORKING TIMES LEARNING BY FOLLOWING THE PROCEDURE IN **CHAPTER 13**

➔ **THE UNIGATE UNIT HAS HUNDREDS OF SPECIFIC FUNCTIONS AND SETTINGS THAT ALLOW ITS USE IN VARIOUS APPLICATIONS AND CONDITIONS; IT ALSO ALLOWS THE CONNECTION OF MANY ACCESSORIES, SUCH AS DIFFERENT TYPES OF ENCODERS OR LIMIT SWITCHES, POTENTIOMETERS, BUTTONS, VARIOUS SAFETY DEVICES, ETC.**


**FOR ALL THESE REASONS, SEA RECOMMENDS TO BROWSE THE COMPLETE TECHNICAL MANUAL BEFORE USE!**

# 1 - MAIN WIRINGS ON «UNILOGIC» MODULE

EXAMPLE OF  
WIRINGS:  
ANTENNA  
START  
PARTIAL START  
STOP  
PHOTOCELLS




EXAMPLE OF WIRINGS:  
FLASHING LAMP AND SAFETY EDGES




EXAMPLE OF WIRINGS: LIMIT SWITCHES

FOR THE LIMIT SWITCHES WIRINGS OF «BIG FAST», «JOINT 4 LS» OR BOLLARDS, SEE THE FULL TECHNICAL MANUAL - CHAPTER 5



BLUE/WHITE → 24  
RED/BROWN → 30  
BLACK/GREEN → 25 (29)

ENCODER (M1)




ENCODER (M2)

BLUE/WHITE → 26  
RED/BROWN → 30  
BLACK/GREEN → 25 (29)

WHITE/BLACK → 24  
GREEN/BLUE → 23  
BROWN → 25 (29)

POTENTIOMETER (M1)



POTENTIOMETER (M2)

WHITE/BLACK → 26  
GREEN/BLUE → 23  
BROWN → 25 (29)


FOR THE WIRINGS OF OTHER ENCODER TYPES AND FOR ENCODER/POTENTIOMETER ADJUSTMENTS, SEE THE FULL TECHNICAL MANUAL

FOR THE CONNECTION OF FURTHER ACCESSORIES, FOR MORE DETAILS ON THE SPECIAL INPUTS «COMIS», «GP1», «GP2», «RELAY 1» AND «RELAY 2» AND FOR ALL DETAILS ON ACCESSORIES SETTINGS, SEE THE FULL TECHNICAL MANUAL



## 2 - MOTOR WIRINGS ON «FV» INVERTER MODULE

### UNIGATE - 1I



**MOTOR 1 (230V)**  
U = BLACK  
V = BLUE  
W = BROWN




DO NOT CONNECT CAPACITORS!



EXEMPLE

### UNIGATE - 2I



**MOTOR 2 (230V)**  
U = BLACK  
V = BLUE  
W = BROWN



DO NOT CONNECT CAPACITORS!




EXEMPLE

## 3 - MOTOR WIRINGS ON «2PM» MODULE


### UNIGATE 2PM

**MOTOR 1 (230V)**  
PHASE 1 = BLACK  
NEUTRAL = BLUE  
PHASE 2 = BROWN



EXEMPLE

**MOTOR 2 (230V)**  
PHASE 1 = BLACK  
NEUTRAL = BLUE  
PHASE 2 = BROWN




EXEMPLE

➡ UNIGATE 4PM: CONNECT THE OTHER TWO OPERATORS ON CN2 AND CN3 OF THE SECOND 2PM MODULE


## 4 - MOTOR WIRINGS ON «24V» MODULE

### UNIGATE 24V



**MOTOR 1 (24V)**  
+ = RED (BROWN)  
- = BLACK (BLUE)

EXEMPLE



**MOTOR 1 (24V)**  
+ = RED (BROWN)  
- = BLACK (BLUE)


EXEMPLE

## 5 - MOTOR WIRINGS ON «BR» 36V MODULE

### UNIGATE BR

**MOTOR 1 (36V)**  
W = BROWN  
V = BLACK  
U = BLUE  
PE = YELLOW/GREEN

CONNECTOR  
ON THE FIRST  
«BR» MODULE




**IT IS MANDATORY  
TO CONNECT  
THE GROUND CABLE  
ON THE «PE» INPUT**



### UNIGATE 2BR

**MOTOR 2 (36V)**  
W = BROWN  
V = BLACK  
U = BLUE  
PE = YELLOW/GREEN


CONNECTOR  
ON THE SECOND  
«BR» MODULE



**IT IS MANDATORY  
TO CONNECT  
THE GROUND CABLE  
ON THE «PE» INPUT**




## 6 - «UNILOGIC» MODULE POWER SUPPLY WIRINGS




- FUSE 16AT DELAYED ON 230V~ POWER SUPPLY  
FUSE 16AT DELAYED ON 115V~ POWER SUPPLY
- USE A 16A DIFFERENTIAL SWITCH TO PROTECT THE POWER SUPPLY SYSTEM
- IN CASE OF UNSTABLE POWER SUPPLY, THE USE OF AN EXTERNAL UPS OF MIN.800VA IS RECOMMENDED

**! FOR THE CONNECTION TO THE POWER GRID  
RESPECT THE LAWS IN FORCE**



## 7 - «FV» MODULE POWER SUPPLY WIRINGS





## 8 - «2PM» MODULE POWER SUPPLY WIRINGS



## 9 - «24V» MODULE POWER SUPPLY WIRINGS



## 10 - «BR» MODULE POWER SUPPLY WIRINGS



## 11 - INPUTS STATUS


- EVERY INPUT CORRESPONDS TO A POSITION ON THE DISPLAY, ACCORDING TO THE DIAGRAM BELOW
- EVERY INPUT CAN BE: **NORMALLY OPEN (0)** - **NORMALLY CLOSED (1)**

0

N.O. - NORMALLY OPEN


1

N.C. - NORMALLY CLOSED



- |                 |                                 |
|-----------------|---------------------------------|
| 1 START (**)    | 9 MOTOR 1 OPENING LIMIT SWITCH  |
| 2 PARTIAL START | 10 MOTOR 1 CLOSING LIMIT SWITCH |
| 3 STOP          | 11 MOTOR 2 OPENING LIMIT SWITCH |
| 4 PHOTOCELL 1   | 12 MOTOR 2 CLOSING LIMIT SWITCH |
| 5 PHOTOCELL 2   | 13 E1/D1 (DATA M1) (*)          |
| 6 SAFETY EDGE 1 | 14 E2/D2 (DATA M2) (*)          |
| 7 SAFETY EDGE 2 | 15 GP1 (*)                      |
| 8 NOT IN USE    | 16 GP2 (*)                      |


\* INPUTS AVAILABLE ONLY IF THE SLOWDOWN LIMIT SWITCHES ARE CONNECTED  
FOR MORE DETAILS, SEE THE FULL TECHNICAL MANUAL



**START AND PARTIAL START MUST BE N.O. (0) - ALL OTHER CONTACTS MUST BE N.C. (1)**



## 12 - «START» COMMAND ON TRANSMITTER QUICK LEARNING




## 13 - WORKING TIMES LEARNING




**DANGER!**

HAVE A QUALIFIED SERVICE PERSON TO CARRY OUT THE OPERATIONS IN SAFE CONDITIONS


### QUICK START - ONLY FOR SEA SLIDING OPERATORS



### PROCEDURE - MORE DETAILS IN THE FULL TECHNICAL MANUAL



➡ IF THE OPERATOR PERFORMS THE FIRST LEARNING CYCLE STARTING IN OPENING, WAIT FOR THE END OF THE CYCLE AND REVERSE THROUGH THE MENU 5:



THEN REPEAT THE LEARNING PROCEDURE

➡ THE WORKING TIMES LEARNING COULD REQUIRE THE INSTALLATION OF LIMIT SWITCHES OR ENCODER OR POTENTIOMETER; FOR THE NECESSARY SETTINGS, CONSULT THE FULL TECHNICAL MANUAL

## MENU FUNCTIONS TABLE - UNIGATE

### LEGEND

**INVERTER** - FUNCTION AVAILABLE ON MODEL UNIGATE WITH "FV" INVERTER MODULE (1I - 2I - 1I BIG - 2I BIG)

**2PM** - FUNCTION AVAILABLE ON MODEL UNIGATE WITH 2PM MODULE

**24V** - FUNCTION AVAILABLE ON MODEL UNIGATE WITH 24V MODULE





**BR** - FUNCTION AVAILABLE ON MODEL UNIGATE WITH BR MODULE

**ALL** - COMMON FUNCTIONS - AVAILABLE ON ALL UNIGATE MODELS

MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
1	LANGUAGE	Italiano	Italian	ALL	English	
		English	English			
		Français	French			
		Español	Spanish			
		Dutch	Dutch			
2	TRANSMITTERS	Start	Start	ALL	Start  Partial opening	
		Partial opening	Partial opening			
		External module	External module			
		Stop	Stop			
		Relay 1	To Activate Relay 1 for 3 seconds. This function requires menu "Relay 1" set on "TX Relay"			
		Relay 2	To Activate Relay 2 for 3 seconds. This function requires menu "Relay 2" set on "TX Relay"			
		Bistable Stop	Pressed once, it stops the gate. Pressed twice, it reactivates the START input			
		Latch opening	One impulse opens and keep open. A second impulse restore the movement			
		Latch closing	One impulse closes and keep closed. A second impulse restore the movement			
		Unlock	To store a command for unlocking the electric brake			
		Delete a transmitter	To delete a single transmitter (TX)			
		Move to EEP	To transfer the transmitters stored on the control unit to the external EEPROM (MEM), if connected			
		Clear memory	To delete the full TX memory on the receiver			
		End	To exit the menu "transmitters"			
3	MOTOR	1- Hydraulic	Hydraulic operators - Series I <b>(INVERTER)</b>	INVERTER 2PM	Hydraulic	
		2- Sliding	Sliding operators - Series I <b>(INVERTER)</b>			
		3- Reversible Sliding	Reversible sliding operators - Series I <b>(INVERTER)</b>			
		4- Electromechanic swing	Electromechanic swing operators - Series I <b>(INVERTER)</b>			
		5- Three-phase - Bollards	Three-phase operators and Bollards Series I BIG <b>(INVERTER with BIG module)</b>			
		7- Barrier	Barriers - Series I <b>(INVERTER)</b>	INVERTER		
		8- BIG Fast BIG Super Fast 4LS	Sliding operators - Series I BIG <b>(INVERTER with BIG module)</b>			
		9- BIG	Sliding operators - Series I BIG <b>(INVERTER with BIG module)</b>			
		10- JOINT 4LS	Hydraulic operator with 4 limit switch <b>Series I (INVERTER)</b>			
		60- BIG RS 485	Sliding operators - Series I BIG <b>(INVERTER with BIG module)</b>			
		61- SEAGEAR RS 485	Sliding operators - Series I BIG <b>(INVERTER with BIG module)</b>			
		62- RAPID DOOR	Electromechanic operator - Series I <b>(INVERTER)</b>			
		64- LEPUS FAST *	Sliding operators - Series I (INVERTER)			

*continues...*

MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
3	MOTOR	32- ORION BOX FAST	24Vdc electromechanic operator	24V	SURF	
		35- SURF	24Vdc electromechanic operator			
		39- HT 270/390 24VDC	24Vdc hydraulic operator			
		43- SURF FAST	24Vdc electromechanic operator			
		65 KITE LS	24Vdc electromechanic operator			
		50- HALF TANK BR	Hydraulic operator - Series BR ( <b>BRUSHLESS</b> )	BR	HALF TANK BR	
		51- SURF BR	Electromechanic swing operator - Series BR ( <b>BRUSHLESS</b> )			
		52- SATURN BR	Electromechanic operator - Series BR ( <b>BRUSHLESS</b> )			
		54- SPRINT BR	Hydraulic barrier - Series BR ( <b>BRUSHLESS</b> )			
		55 KITE LS BR	Operatore elettromeccanico - Serie BR ( <b>BRUSHLESS</b> )			
		56- COMPACT BR	Hydraulic operator - Series BR ( <b>BRUSHLESS</b> )			
		57- JOINT BR	Operatore idraulico - Serie BR ( <b>BRUSHLESS</b> )			
		58- LEPUS BR (ABC)	Scorrevole con Encoder ABC - Serie BR ( <b>BRUSHLESS</b> )			
* Only for LEPUS FAST 220V. In case of LEPUS FAST 110V, choose the option 2-Sliding						
4	GATES NUMBER	From 1 to 2	To set the number of motors to be managed	INVERTER 24V - BR	1	
		From 1 to 4		2PM	2	
5	REVERSE MOTOR	On	To reverse the opening with the closing or vice-versa <b>(both motors and limit-switches are reversed)</b>	ALL	Off	
		Off	Off			
6	LOGIC	Automatic	Automatic	ALL	Auto- matic	
		Open-stop-close-stop-open	Step by step type 1			
		Open-stop-close-open	Step by step type 2			
		2 button	Two buttons			
		Safety	Safety			
		Dead man	Dead man			
7	PAUSE TIME	Off	Semi-automatic logic - <b>(a START command opens and another START closes - automatic closing disabled)</b>	ALL	Off	
		1 240	Setting from 1 second to 4 minutes			
8	START IN PAUSE	Off	The Start command is not accepted during pause	ALL	Off	
		On	The Start command is accepted during pause			
9	PROGRAMMING	Off On	To start the working times self-learning	ALL	Off	
		Choose direction	<b>This menu is shown only if an Encoder RS 485 is connected</b> - it allows to program one or two operators with RS 485 Encoder, in automatic or manual mode	INVERTER 24V BR		
10	TEST START	Off On	To give a Start command for testing the automation	ALL	Off	
11	BEAM LENGTH	3m - 4m - 5m - 6m 7m - 7,5m - 8m	This menu will be shown only if the option <b>7-Barrier is set in the menu 3-MOTORS</b> . It allows to choose the beam length <b>(values in meters)</b>	INVERTER BR	----	
12	SLOWDOWN LIMIT SWITCH	Off On	This menu will be shown only if the option <b>5-Threephase/Bollards is set in the menu 3-MOTORS</b> . It allows to activate the slowdown limit switch <u>on bollards</u>	INVERTER	Off	
13	LATCH PAUSE	Off On	If "ON" the operator complies with the pause time set when the function "LATCH OPENING" is disabled. When "OFF" the pause time set is not respected	INVERTER 24V BR	Off	

MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
14	RESET		A count-down of 5 seconds will start by holding the UP button; at its end "INIT" will appear on the display as confirmation of the control board reset			
192	MOVE GATE 1 *		Allows the movement of the gate in a temporary "dead man" mode <i>(for example to test the correct running of the motor)</i> HOLD <b>UP</b> PRESSED = THE GATE OPENS HOLD <b>DOWN</b> PRESSED = THE GATE CLOSES <div>   </div>	INVERTER 24V BR	----	
193	MOVE GATE 2 *		Allows the movement of the gate in a temporary "dead man" mode <i>(for example to test the correct running of the motor)</i> HOLD <b>UP</b> PRESSED = THE GATE OPENS HOLD <b>DOWN</b> PRESSED = THE GATE CLOSES <div>   </div>	INVERTER 24V BR	----	
* The command is accepted only at the end of the cycle or after a STOP; it is not accepted during the cycle and during the pause						
15	END		Press OK to return to the display of the firmware version and to the one of inputs state			
16	SPECIAL MENU		Press OK to enter the special menu			



UP DOWN

# SPECIAL MENU

PRESS AT THE SAME TIME FOR 5 SECONDS TO ENTER OR TO EXIT THE SPECIAL MENU

## LEGEND

**INVERTER** - FUNCTION AVAILABLE ON MODEL UNIGATE WITH "FV" INVERTER MODULE (1I - 2I - 1I BIG - 2I BIG)**2PM** - FUNCTION AVAILABLE ON MODEL UNIGATE WITH 2PM MODULE**24V** - FUNCTION AVAILABLE ON MODEL UNIGATE WITH 24V MODULE**BR** - FUNCTION AVAILABLE ON MODEL UNIGATE WITH BR MODULE**ALL** - COMMON FUNCTIONS - AVAILABLE ON ALL UNIGATE MODELS

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
17	OPENING SPEED 1	10 100	Speed in opening Motor 1	INVERTER	80	
		20 100		24V		
		30 100		BR		
18	CLOSING SPEED 1	10 100	Speed in closing Motor 1	INVERTER	80	
		20 100		24V		
		30 100		BR		
19	OPENING SPEED 2	10 100	Speed in opening Motor 2	INVERTER	80	
		20 100		24V		
		30 100		BR		
20	CLOSING SPEED 2	10 100	Speed in closing Motor 2	INVERTER	80	
		20 100		24V		
		30 100		BR		
21	SLOWDOWN SPEED IN OPENING 1	From 10% to 60% of the maximum speed	slowdown speed in opening Motor 1	INVERTER 24V - BR	30	
22	SLOWDOWN SPEED IN CLOSING 1	From 10% to 60% of the maximum speed	slowdown speed in closing Motor 1	INVERTER 24V - BR	30	
23	SLOWDOWN SPEED IN OPENING 2	From 10% to 60% of the maximum speed	slowdown speed in opening Motor 2	INVERTER 24V - BR	30	
24	SLOWDOWN SPEED IN CLOSING 2	From 10% to 60% of the maximum speed	slowdown speed in closing Motor 2	INVERTER 24V - BR	30	
25	LEARNING SPEED	10% 100 %	To adjust the time self-learning speed. This parameter can change according to the motor type set	INVERTER	50	
		20% 100 %		24V BR		



**NOTE: The range of values that can be set in all the SPEED menus may vary according to the operator model**

26	LEAF DELAY IN OPENING	Off 6 Total	Adjustable from Off to 6 seconds to "Total" (if on "Total" the Motor2 will start opening only after the Motor1 has completed the movement)	INVERTER 24V BR	1,5	
		Off 6	Adjustable from OFF (disabled) to 6 seconds	2PM		
27	LEAF DELAY IN CLOSING	Off 20 Total	Adjustable from Off to 20 seconds to "Total" (if on "Total" the Motor1 will start closing only after the Motor2 has completed the movement)	INVERTER 24V BR	2,5*	
		Off 20	Adjustable from OFF (disabled) to 20 seconds	2PM		
28	OPENING TORQUE 1	50% 100 %	<b>Motor 1 opening torque:</b> by increasing the torque, more strength will be required to execute the inversion in case of obstacle	INVERTER 2PM	100%	
		10% 100 %		24V		
		5% 100 %		BR		
29	CLOSING TORQUE 1	50% 100 %	<b>Motor 1 closing torque:</b> by increasing the torque, more strength will be required to execute the inversion in case of obstacle	INVERTER 2PM	100%	
		10% 100 %		24V		
		5% 100 %		BR		
30	OPENING TORQUE 2	50% 100 %	<b>Motor 2 opening torque:</b> by increasing the torque, more strength will be required to execute the inversion in case of obstacle	INVERTER 2PM	100%	
		10% 100 %		24V		
		5% 100 %		BR		
31	CLOSING TORQUE 2	50% 100 %	<b>Motor 2 closing torque:</b> by increasing the torque, more strength will be required to execute the inversion in case of obstacle	INVERTER 2PM	100%	
		10% 100 %		24V		
		5% 100 %		BR		

**NOTE: The range of values that can be set in all the TORQUE menus may vary according to the operator model**



SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
32	ENCODER	On	ON = Encoder enabled OFF = Encoder disabled (when OFF, the working times learnt are only shown)	ALL	It depends on motor	
		Enc ABC	To enable the rotary Encoder for the management of the brushless operator and its position	BR	It depends on motor	
	47 ENCODER PAR.1	xxx.	Impulses read by Encoder during operation (Motor1)			
	48 ENCODER TOT. 1	xxx.	Impulses stored during programming (Motor 1)			
	49 ENCODER PAR.1	xxx.	Impulses read by Encoder during operation (Motor2)			
	50 ENCODER TOT. 2	xxx.	Impulses stored during programming (Motor 2)			
32	ENCODER	Potentiometer	To enable the reading of the potentiometer	ALL	Off	
		Absolute	To enable the reading of the absolute Encoder	INVERTER BR		
		RS 485	To enable the reading of the absolute rotative Encoder	INVERTER 24V - BR		
	51 I.PAR.M1 *	-----	To show the current position of the potentiometer on the leaf moved by Motor 1. This parameter is useful to see if the potentiometer is correctly read			
	52 I.AP.M1	From the value learnt to ± 100 pulses	To show the impulses stored by the control unit when the leaf moved by Motor 1 is fully open			
	53 I.CH.M1	From the value learnt to ± 100 pulses	To show the impulses stored by the control unit when the leaf moved by Motor 1 is fully close			
	54 I.PAR.M2 *	-----	To show the current position of the potentiometer on the leaf moved by Motor 2. This parameter is useful to see if the potentiometer is correctly read			
	55 I.AP.M2	From the value learnt to ± 100 pulses	To show the impulses stored by the control unit when the leaf moved by Motor 2 is fully open			
	56 I.CH.M2	From the value learnt to ± 100 pulses	To show the impulses stored by the control unit when the leaf moved by Motor 2 is fully close			
* While the partial impulses are displayed, it is possible to OPEN (by pressing UP) or CLOSE (by pressing DOWN) the corresponding operator to verify the correct reading of the potentiometer after installation or simply for checking						
32	ENCODER	Off	ON = Encoder enabled OFF = Encoder disabled (when OFF, the working times learnt are only shown)	ALL	Off	
	65 OPENING TIME M1	xxx.s	To display the learnt value during the working times self learning, in opening and closing (Motor 1). With UP or DOWN it is possible to increase or reduce the working times			
	66 CLOSING TIME M1	xxx.s				
	67 OPENING TIME M2	xxx.s	To display the learnt value during the working times self learning, in opening and closing (Motor 2). With UP or DOWN it is possible to increase or reduce the working times			
	68 CLOSING TIME M2	xxx.s				
33	OPENING SENSITIVITY MOTOR 1	10% (Fast intervention) 99% (Slow intervention)	To adjust the Encoder or Potentiometer intervention time on Motor 1 in opening	ALL	Off	
		Off (Intervention excluded)	Disabled			
34	CLOSING SENSITIVITY MOTOR 1	10% (Fast intervention) 99% (Slow intervention)	To adjust the Encoder or Potentiometer intervention time on Motor 1 in closing	ALL	Off	
		Off (Intervention excluded)	Disabled			
35	OPENING SENSITIVITY MOTOR 2	10% (Fast intervention) 99% (Slow intervention)	To adjust the Encoder or Potentiometer intervention time on Motor 2 in opening	ALL	Off	
		Off (Intervention excluded)	Disabled			
36	CLOSING SENSITIVITY MOTOR 2	10% (Fast intervention) 99% (Slow intervention)	To adjust the Encoder or Potentiometer intervention time on Motor 2 in closing	ALL	Off	
		Off (Intervention excluded)	Disabled			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
37	SLOWDOWN SENSITIVITY MOTOR	10% (Fast intervention) 99% (Slow intervention)	To adjust the amperometric sensitivity in slowdown <b>Function available only on electro-mechanic operators</b>	ALL	Off	
		With potentiometer	To set the inversion time in slow-down from 0 to 5 seconds (= 99%) - <b>Only with potentiometer enabled</b>		30%	
38	POTENTIOMETER 1 THRESHOLD IN OPENING	1 1000 (only if the Menu 32 is set on "Potentiometer")	To adjust the threshold of the potentiometer intervention. This parameter self-determines during the working times learning but can also be adjusted later, on the condition that the set value is higher than the value shown in VP1 or VP2 (instantaneous speed values which can be shown by accessing the DEBUG menu). <b>NOTE: The lower the threshold value, the slower will be the response of the potentiometer.</b>	ALL	----	
39	POTENTIOMETER 1 THRESHOLD IN CLOSING					
40	POTENTIOMETER 2 THRESHOLD IN OPENING					
41	POTENTIOMETER 2 THRESHOLD IN CLOSING					
42	POTENTIOMETER 1 OPENING SLOW DOWN THRESHOLD	1 100 (only if the Menu 32 is set on "Potentiometer")	To adjust the threshold of the potentiometer intervention in slowdown. By default this value is set on 10. but can be manually increased on the condition that the set value is higher than the value shown in VP1 or VP2 (instantaneous speed values which can be shown by accessing the DEBUG menu)	ALL	15	
43	POTENTIOMETER 1 CLOSING SLOW DOWN THRESHOLD					
44	POTENTIOMETER 2 OPENING SLOW DOWN THRESHOLD					
45	POTENTIOMETER 2 CLOSING SLOW DOWN THRESHOLD					
46	CLOSING INVERSION	Total	In case of obstacle or safety edge it totally reverses the movement during closing. If active, the automatic reclosing will be attempted for 5 times	ALL	Total	
		Partial	In case of obstacle, safety edge or potentiometer, it partially reverses direction (of about 30 cm) then stops			
For menu 47 and 50 see menu 32-Encoder = On						
For menu from 51 to 56 see menu 32-Encoder = Potentiometer						
57	WORKING CURRENT 1	..... Ampere	To display the absorbed current during Motor 1 working	INVERTER 24V BR	----	
58	WORKING CURRENT 2	..... Ampere	To display the absorbed current during Motor 2 working	INVERTER 24V BR	----	
59	OPENING SLOWDOWN 1	0 50	From 0% to 50% of the stroke (0% = slowdown excluded)	ALL	30	
60	CLOSING SLOWDOWN 1	0 50	From 0% to 50% of the stroke (0% = slowdown excluded)	ALL	30	
61	OPENING SLOWDOWN 2	0 50	From 0% to 50% of the stroke (0% = slowdown excluded)	ALL	30	
62	CLOSING SLOWDOWN 2	0 50	From 0% to 50% of the stroke (0% = slowdown excluded)	ALL	30	
63	DECELERATION	0 % 100% 	To adjust the change from normal speed to slowdown speed	ALL	It depends on motor	
64	ACCELERATION	0,1 s 5 s 	Acceleration ramp. To adjust the motor start	ALL	It depends on motor	
For menu from 65 to 68 see menu 32-Encoder = Off (They are visible even with 32-Encoder set ON)						

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
69	ANTI OVERLAP	Off	To disable the anti-overlapping control of the leaves allowing their separate control	ALL	Off	
		On	To enable the anti-overlapping control of the leaves			
70	OPENING POSITION RECOVERY	0 20 seconds (only if 32-Encoder is OFF)	To retrieve the inertia of the motor in opening after the Stop or the reversing	ALL	It depends on motor	
71	CLOSING POSITION RECOVERY	0 20 seconds (only if 32-Encoder is OFF)	To retrieve the inertia of the motor in closing after the Stop or the reversing	ALL	It depends on motor	
72	OPENING TOLERANCE MOTOR 1	0% 100%	To adjust the Motor 1 tolerance between the stop and the obstacle, in opening	ALL	20%	
73	CLOSING TOLERANCE MOTOR 1	0% 100%	To adjust the Motor 1 tolerance between the stop and the obstacle, in closing	ALL	20%	
74	OPENING TOLERANCE MOTOR 2	0% 100%	To adjust the Motor 2 tolerance between the stop and the obstacle, in opening	ALL	20%	
75	CLOSING TOLERANCE MOTOR 2	0% 100%	To adjust the Motor 2 tolerance between the stop and the obstacle, in closing	ALL	20%	
76	PUSHING STROKE	Time Pushing Off - 3 sec Stroke	Before opening, the motor starts in closing for the time set, in order to simplify the lock release	ALL	Off	
		Repeat Lock Release Off – On	If <b>ON</b> , the lock will be released both before and after the pushing stroke			
		End				
77	LOCK TIME	Off 5	To adjust the lock release time from 0 to 5 seconds	ALL	3	
78	LOCK	Only opening	Lock enabled only before opening	ALL	Only opening	
		Only closing	Lock enabled only before closing			
		Opening and closing	Lock enabled before opening and closing			
79	ANTI INTRUSION	Only opening	If the gate is forced manually, the control unit starts the motor and restores the state of the gate before forcing <b>(function only available if limit switches are installed)</b>	ALL	Off	
		Only closing				
		Opening and closing				
		Off				
80	PUSHOVER	Off	The gate leaf makes an extra movement at the maximum torque to ensure the tightening of the gate	ALL	Off	
		Opening and closing				
		Only closing				
		Only opening				
81	PERIODICAL PUSHOVER	Off 8h (only if 80-Pushover is ON)	To activate the repetition of the pushover function at a distance of time adjustable from 0 to 8 hours, at hourly intervals	ALL	Off	
82	MOTOR RELEASE	Opening 1 Off - 3 s	If different from OFF, the operator slightly reverses its direction at the end of the cycle	ALL	It depends on motor	
		Closing 1 Off - 3 s				
		Opening 2 Off - 3 s				
		Closing 2 Off - 3 s				
		End				
83	EXTRA TIME	Opening1 Off - 10s	If the limit switches are installed, it is possible to add an extra time <b>(max. 10 seconds)</b> to the movement of the operators after the reading of the limit switches	INVERTER 24V BR	1.0 s	
		Closing 1 Off - 10s				
		Opening2 Off - 10s				
		Closing 2 Off - 10s				
		EXIT				
		0.0 s 10 s		2PM		
85	PRE-FLASHING	Only closing	To enable the pre-flashing only before closing <b>(to access: push DOWN button when 0.0 value is shown)</b>	ALL	0.0 s	
		0.0 5.0 s	To set the pre-flashing duration			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
86	FLASHING LIGHT	<i>Normal</i>	Normal	ALL	Normal	
		<i>Light</i>	Warning lamp function			
		<i>Always</i>	Always ON			
		<i>Buzzer</i>	Buzzer			
87	FLASHING LIGHT AND TIMER	<i>Off</i>	The flashing light will be OFF with enabled timer and open gate	ALL	Off	
		<i>On</i>	The flashing light will be ON with enabled timer and open gate			
88	COURTESY LIGHT	<i>Off</i>	Disabled	ALL	In cycle	
		<i>1      240</i>	Adjustable from 1 second to 4 minutes			
		<i>In cycle</i>	Courtesy light only in cycle			
89	TRAFFIC LIGHT RESERVATION	<i>Off    On</i>	To get the priority in entry or exit. <b>Available by the use of the partial opening contact</b>	ALL	Off	
90	PARTIAL OPENING	<i>5%    100%</i>	Adjustable from 5% to 100%	ALL	50%	
91	PARTIAL PAUSE	<i>= Start</i>	The pause in partial opening is the same as in total opening	ALL	= Start	
		<i>Off</i>	Disabled			
		<i>1      240</i>	Adjustable from 1 second to 4 minutes			
92	TIMER	<i>Off</i>	To turn the selected input into an input to which connect an external clock	ALL	Off	
		<i>On photo2</i>				
		<i>On partial input</i>				
		<i>Clock</i>				
93	FIRE SWITCH	<i>Off</i>	Disabled	ALL	Off	
		<i>On Photo2</i>	Function enabled on the Photocell 2 input			
		<i>On partial input</i>	Function enabled on the partial opening Start input			
94	24V AUX (Max. 500 mA)	<i>Always</i>	AUX output always powered	ALL	Always	
		<i>In cycle</i>	AUX output powered only during cycle			
		<i>Opening</i>	AUX output powered only during opening			
		<i>Closing</i>	AUX output powered only during closing			
		<i>In pause</i>	AUX output powered only during pause			
		<i>Phototest</i>	AUX output powered for safety devices testing			
		<i>In cycle and phototest</i>	AUX output powered during cycle only and for safety devices testing			
		<i>In cycle and pause</i>	AUX output powered during cycle and during pause			
		<i>Courtesy light (connected via relay)</i>	To connect an additional courtesy light via relay. Management according to the Menu-88 settings			
		<i>Barrier and Bollard LED lights</i>	<b>Closed operator</b> - the light is switched-on <b>Open operator</b> - the light is switched-off <b>Moving operator</b> - the light blinks			
		<i>Open gate warning light (connected via relay)</i>	<b>1 flash per second</b> during opening <b>2 flashes per second</b> during closing <b>Steady lit</b> in "Stop" or "Open" status			
		<i>Fan (connected via relay)</i>	AUX output powered during cycle and for 2 additional minutes after the end of the cycle	INVERTER		

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
95	PHOTO-TEST	Photo 1	Self-test enabled only on photocell 1	ALL	Off	
		Photo 2	Self-test enabled only on photocell 2			
		Photo 1 and 2	Self-test enabled on photocells 1 and 2			
		Off	Disabled			
96	SAFETY EDGE SELF-TEST	Edge 1	Self-test enabled only on safety edge 1	ALL	Off	
		Edge 2	Self-test enabled only on safety edge 2			
		Edges 1 and 2	Self-test enabled on safety edges 1 and 2			
		Off	Disabled			
97	PHOTOCELL 1	Closing	If the photocell is occupied during closing, the gate reverses the movement; If the photocell is occupied during the pause, it prevents the gate reclosing	ALL	Closing	
		Opening and closing	If the photocell is occupied during opening or closing, it stops the gate movement; when the photocell is released, the movement continues			
		Stop	If the photocell is occupied before the Start input, the Start will be ignored. If the photocell is occupied after the Start input, the photocell will be ignored. If the photocell is occupied during closing, the gate will reopen			
		Stop and close	If the photocell is occupied during closing, it stops the gate movement; when released, the closing movement continues			
		Close	The photocell stops the gate until it is occupied in both opening and closing; when released, the photocell gives a closing command <b>(the gate closes one second after the photocell release)</b>			
		Closing Pause reloading	If the photocell is occupied during the pause, it reloads the same pause time set. If the photocell is occupied in closing, it reverses the gate movement			
		Opening and Closing Pause reloading	If the photocell is occupied during the pause, it reloads the pause time set. If the photocell is occupied during the closing, it reverses the gate movement; If the photocell is occupied during the opening, it stops the gate and when released, the opening movement continues			
		Shadow loop *	When the gate is open, the shadow loop prevents the reclosing until it is occupied. The Shadow loop is switched off during closing			
		Delete pause time	If the photocell is occupied during opening, pause or closing, the gate reopens completely and closes without observing the pause time set			
		Shadow loop PR (pause reloading) *	When the gate is open, the shadow loop prevents the reclosing until it is occupied. When released, the gate repeats the pause time set, then it closes. The Shadow loop is switched off during closing			
<b>* If the module 2PM is in use, the shadow loop does not enable when the menu-121 is seto to "Photo 1 10K"</b>						



SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
98	PHOTOCELL 2	Closing	If the photocell is occupied during closing, the gate reverses the movement; If the photocell is occupied during the pause, it prevents the gate reclosing	ALL	Opening and closing	
		Opening and closing	If the photocell is occupied during opening or closing, it stops the gate movement; when the photocell is released, the movement continues			
		Stop	If the photocell is occupied before the Start input, the Start will be ignored. If the photocell is occupied after the Start input, the photocell will be ignored. If the photocell is occupied during closing, the gate reopens			
		Stop and close	If the photocell is occupied during closing, it stops the gate; when released, the closing movement continues			
		Close	The photocell stops the gate until it is occupied in both opening and closing; when released, the photocell gives a closing command <b>(the gate closes one second after the photocell release)</b>			
		Opening Pause reloading	If the photocell is occupied during the pause, it recharges the same pause time set. If the photocell is occupied during the opening, the gate stops and when released, the movement continues			
		Pause reload Photo closing	If the photocell is occupied during the pause, it reloads the pause time set. If the photocell is occupied during closing, the gate reverses the movement			
		Opening and Closing Pause reloading	If the photocell is occupied during the pause, it reloads the pause time set. If the photocell is occupied during the closing, it reverses the movement; If the photocell is occupied during the opening, it stops the gate and when released, the opening continues			
		Shadow loop *	When the gate is open, the shadow loop prevents the reclosing until it is occupied. The Shadow loop is switched off during closing			
		Delete pause time	If the photocell is occupied during opening, pause or closing, the gate reopens completely and closes without observing the pause time set			
		Shadow loop PR (pause reloading) *	When the gate is open, the shadow loop prevents the reclosing until it is occupied. When released, the gate repeats the pause time set, then it closes. The Shadow loop is switched off during closing			
		Stop and open	If the photocell is occupied during opening, the gate stops; when released, the gate continues the opening movement. The photocell is ignored during closing			
* If the module 2PM is in use, the shadow loop does not enable when the menu-121 is seto to "Photo 1 10K"						
99	PHOTO OFF IN CLOSING	0%      50%	In closing, this function excludes the photocell reading for the space percentage set	INVERTER 24V	0%	
100	SAFETY EDGE 1	Normal	Normal N.C. contact	ALL	Normal	
		8K2 N.C.	Safety edge protected by a 8K2 resistor enabled			
		8K2 N.C. Double	Two safety edges protected by 8K2 resistor enabled			
		8K2 RES	Resistive edge protected by 8K2 resistor enabled			
		8K2 RES Double	Two resistive edges protected by 8K2 RES enabled			
101	SAFETY EDGE 2	Normal	Normal N.C. contact	ALL	Normal	
		8K2 N.C.	Safety edge protected by a 8K2 resistor enabled			
		8K2 N.C. Double	Two safety edges protected by 8K2 resistor enabled			
		8K2 RES	Resistive edge protected by 8K2 resistor enabled			
		8K2 RES Double	Two resistive edges protected by 8K2 RES enabled			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
102	SAFETY EDGE 1 DIRECTION	Opening and closing	Safety edge enabled in opening and closing	ALL	Opening and Closing	
		Only opening	Safety edge enabled only in opening			
		Only closing	Safety edge enabled only in closing			
103	SAFETY EDGE 2 DIRECTION	Opening and closing	Safety edge enabled in opening and closing	ALL	Opening and Closing	
		Only opening	Safety edge enabled only in opening			
		Only closing	Safety edge enabled only in closing			
104	SELECT LIMIT SWITCH	N. C.	Limit switch type N.C. <b>(Normally Closed)</b> <b>Example: inductive limit switch or with lever</b>	INVERTER 24V	N.C.	
		Ext	Limit switch connected on the external interface <b>for 4 cams limit switches</b>			
		N.O.	Limit switch type N.O. <b>(Normally Open)</b> <b>Example: magnetic limit switch</b>			
		Automatic	Automatic detection of the limit switch	2PM	Automatic	
		Opening only	Limit switch enabled only in opening			
		Closing only	Limit switch enabled only in closing			
		Ext	Limit switch connected on the external interface <b>for 4 cams limit switches</b>			
		Motor internal	To be enabled if the operator is equipped with an inner limit switch that stops the motor phase			
105	PRIMARY/SECONDARY (MASTER/SLAVE)	Primary	To set the control unit as PRIMARY on applications with two operators in primary/secondary mode	INVERTER BR	Off	
		Secondary	To set the control unit as SECONDARY on applications with two operators in primary/secondary mode			
		Off	Disabled			
106	DIAGNOSTICS	1        10	To display the last event <b>(See alarms table)</b>	ALL	----	
107	MAINTENANCE CYCLES	100    240000	Adjustable from 100 to 240000 cycles	ALL	100000	
108	PERFORMED CYCLES	0        240000	To display the executed cycles. <b>Hold pressed OK to reset the cycles</b>	ALL	0	
109	THERMOMETER	xx °C        (xx °C )	To display the temperature if a probe is connected on GP1 or GP2 (and the menus 130 and 131 are set on "Thermometer") The connection of up to two temperature probes is allowed; <b>(display will show both temperatures detected)</b>	ALL	Off	
110	LOWER THRESHOLD TEMPERATURE	From -20° to +50°	To adjust the temperature threshold of the oil heater probe activation <b>(This menu is shown only if the menu 109-Thermometer is set to ON)</b>	ALL	-10°	
111	UPPER THRESHOLD TEMPERATURE	From -20° to +50°	To adjust the temperature threshold of the oil heater probe deactivation <b>(This menu is shown only if the menu 109-Thermometer is set to ON)</b>	ALL	0°	
112	PASSWORD	<b>Note: "0000" setting is not allowed</b>	To enter a password for blocking the control unit parameters modification	ALL	----	

SPECIAL MENU		SET		DESCRIPTION	MODEL	DEFAULT	NOTE
113	EMERGENCY	<i>Off</i>		Disabled	ALL	<i>Off</i>	
		<i>Emergency</i>		In case of power failure and with batteries connected and charged, the gate opens completely and remains open until the power is restored			
		<i>Last opening</i>		In case of power failure, as soon as the battery charge drops below 22V, the gate opens one last time and remains open until the power is restored			
		<i>Last closing</i>		In case of power failure, as soon as the battery charge drops below 22V, the gate closes one last time and remains closed until the power is restored			
115	DECELERATION RAMP	0,1 s	5s	Deceleration management in case of inversion or Stop command	INVERTER 24V BR	0,5 s	
116	REPEAT LEAF DELAY	<i>On</i>	<i>Off</i>	In case of a STOP command when the gate is on its halfway, the leaves will repeat the "leaf delay" set on menus 26-27	ALL	<i>On</i>	
117	ALWAYS CLOSE	<i>Off</i>	240 seconds	In case of power failure, if the gate has been manually open, it closes only after the set time has elapsed ( <b>from 0 to 240 seconds</b> ) as soon as the power is restored	ALL	<i>Off</i>	
118	LATCH	<i>Off</i>		Disabled	ALL	<i>Off</i>	
		<i>Opening</i>		The gate opens and stay open till a new Start input. <b>The latch function uses the "Safety Edge 1" N.O. input (Safety Edge 1 function is so disabled)</b>			
		<i>Closing</i>		The gate closes and stay closed till a new Start input. <b>The latch function uses the "Safety Edge 2" N.O. input (Safety Edge 2 function is so disabled)</b>			
		<i>Opening and closing</i>		To enables both the opening and closing functions above described. <b>The latch function uses the "Safety Edge 1" and "Safety Edge 2" N.O. inputs (both safety edges are so disabled)</b>			
119	DISPLAY WRITING SPEED	From 30% to 100%		See Note 2 at the end of the table	ALL	80%	
120	BASIC MENU	Press OK to exit the special menu. The special menu switches off automatically after 20 minutes					
121	PHOTO 1 TYPE	<i>Normal</i>		Standard photocell without 10K control	ALL	<i>Normal</i>	
		<i>Photo 1 10K</i>		Photocell with 10K control			
		<i>Photo 1 10K DOUBLE</i>		Double photocell with 10K control	2PM		
122	PHOTO 2 TYPE	<i>Normal</i>		Standard photocell without 10K control	ALL	<i>Normal</i>	
		<i>Photo 2 10K</i>		Photocell with 10K control			
		<i>Photo 2 10K DOUBLE</i>		Double photocell with 10K control	2PM		
123	DATE AND TIME	<i>Mon - Sun dd/mm/yyyy Time</i>		To set the day, the date and the time for the management of the programmed openings. <b>(Only with full charge buffer battery)</b>	ALL	----	
124	CLOCK 1	<i>Opening time</i>		To set a first time band in which keeping the gate open.	ALL	<i>Off</i>	
		<i>Closing time</i>		It is possible to set, in order: opening time, closing time and the days on which you want to open and keep the gate open			
		<i>Days</i>					
		<i>Modify</i>		To modify the pre-set time and day			
		<i>Exit</i>		Exit from menu			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
125	CLOCK 2	Opening time	To set a second time band in which keeping the gate open. It is possible to set, in order: opening time, closing time and the days on which you want to open and keep the gate open	ALL	Off	
		Closing time				
		Days				
		Modify	To modify the pre-set time and day			
		Exit	Exit from menu			
126	CLOCK 3	Opening time	To set a third time band in which keeping the gate open. It is possible to set, in order: opening time, closing time and the days on which you want to open and keep the gate open	ALL	Off	
		Closing time				
		Days				
		Modify	To modify the pre-set time and day			
		Exit	Exit from menu			
127	CLOCK 4	Opening time	To set a fourth time band in which keeping the gate open. It is possible to set, in order: opening time, closing time and the days on which you want to open and keep the gate open	ALL	Off	
		Closing time				
		Days				
		Modify	To modify the pre-set time and day			
		Exit	Exit from menu			
130	GP1	Off	Disabled	ALL	Off	
		Open	To connect an opening button that allows the automation operating in "Dead Man" logic. The button will only work when the gate is closed or after a Stop command			
		Emergency open	To connect an opening button that allows the automation operating in "Dead Man" logic. The button will only work in case of safety devices failure or in case of stuck Start button			
		Thermometer	To connect a temperature probe for the detection of an external temperature which will be shown on the display by accessing menu 109-THERMOMETER ( <i><b>probe for detection of hydraulic motor oil temperature</b></i> )			
		Cage	To control the Motor 1 only if the Motor 2 is closed	INVERTER 24V		
131	GP2	Off	Disabled	ALL	Off	
		Close	To connect a closing button that allows the automation operating in "Dead Man" logic. The button will only work when the gate is closed or after a Stop command			
		Emergency close	To connect an closing button that allows the automation operating in "Dead Man" logic. The button will only work in case of safety devices failure or in case of stuck Start button			
		Thermometer	To connect a temperature probe for the detection of an external temperature which will be shown on the display by accessing menu 109-THERMOMETER ( <i><b>probe for detection of hydraulic motor oil temperature</b></i> )			
		Cage	To control the Motor 2 only if the Motor 1 is closed	INVERTER 24V		

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
132	RELAY 1	<i>Off</i>	Disabled	ALL	Off	
		<i>Start 3s</i>	To enable the Relay 1 for 3 seconds at every Start or reopening command			
		<i>Traffic light 1</i>	Traffic light management: the green light is switched-on only when the gate is open			
		<i>Traffic light in entrance</i>	By a Start command the traffic light in entrance turns green and the access priority is acquired while the traffic light in exit turns red. <b>(with menu 89-TRAFFIC LIGHT BY RESERVATION in ON)</b>			
		<i>Traffic light in exit</i>	By a Start command the traffic light in exit turns green and the access priority is acquired while the traffic light in entrance turns red. <b>(with menu 89-TRAFFIC LIGHT BY RESERVATION in ON)</b>			
		<i>Lock copy</i>	The Relay 1 will be ON for the time set on 78-LOCK menu			
		<i>Flashing light copy</i>	The Relay 1 repeats the flashing-light functions			
		<i>Courtesy light copy</i>	The Relay 1 will be ON for the time set on 88-COURTESY LIGHT menu			
		<i>Fire-switch copy</i>	The Relay 1 repeats the menu 93-fireswitch functions			
		<i>Opening 1 limit switch</i>	The Relay 1 will be ON if the motor 1 opening limit switch is activated or if the motor 1 is in "Open" status			
		<i>Closing 1 limit switch</i>	The Relay 1 will be ON if the motor 1 closing limit switch is activated or if the motor 1 is in "Closed" status			
		<i>Opening 2 limit switch</i>	The Relay 1 will be ON if the motor 2 opening limit switch is activated or if motor 2 is in "Open" status			
		<i>Closing 2 limit switch</i>	The Relay 1 will be ON if the motor 2 closing limit switch is activated or if the motor 2 is in "Closed" status			
		<i>Tx Relay</i>	It is possible to activate the Relay 1 for 3 seconds by giving an impulse from the remote control			
		<i>Negative brake and Photocell 1 management</i>	The negative electric-brake is not active on the photocell intervention			
		<i>Negative brake 1 management</i>	Negative electric-brake <b>(in ON with the gate in cycle and 1 second before the Start input)</b>			
		<i>Positive brake 1 management</i>	Positive electric-brake <b>(in ON with stationary gate)</b>			
		<i>Opening electric-valve</i>	The Relay 1 is active during opening			
		<i>Closing electric-valve</i>	The Relay 1 is active during closing			
		<i>Clock 1 and 2</i>	The Relay will be active in the same time band set on menus 124 e 125			



SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
133	RELAY 2	<i>Off</i>	Disabled	ALL	Off	
		<i>Start 3s</i>	To enable the Relay 2 for 3 seconds at every Start or reopening command			
		<i>Traffic light 1</i>	Traffic light management: the green light is switched-on only when the gate is open			
		<i>Traffic light in entrance</i>	By a Start command the traffic light in entrance turns green and the access priority is acquired while the traffic light in exit turns red. <b>(with menu 89-TRAFFIC LIGHT BY RESERVATION in ON)</b>			
		<i>Traffic light in exit</i>	By a Start command the traffic light in exit turns green and the access priority is acquired while the traffic light in entrance turns red. <b>(with menu 89-TRAFFIC LIGHT BY RESERVATION in ON)</b>			
		<i>Lock copy</i>	The Relay 2 will be ON for the time set on 78-LOCK menu			
		<i>Flashing light copy</i>	The Relay 2 repeats the flashing-light functions			
		<i>Courtesy light copy</i>	The Relay 2 will be ON for the time set on 88-COURTESY LIGHT menu			
		<i>Fire-switch copy</i>	The Relay 2 repeats the menu 93-fireswitch functions			
		<i>Opening 1 limit switch</i>	The Relay 2 will be ON if the motor 1 opening limit switch is activated or if the motor 1 is in "Open" status			
		<i>Closing 1 limit switch</i>	The Relay 2 will be ON if the motor 1 closing limit switch is activated or if the motor 1 is in "Closed" status			
		<i>Opening 2 limit switch</i>	The Relay 2 will be ON if the motor 2 opening limit switch is activated or if motor 2 is in "Open" status			
		<i>Closing 2 limit switch</i>	The Relay 2 will be ON if the motor 2 closing limit switch is activated or if the motor 2 is in "Closed" status			
		<i>Tx Relay</i>	It is possible to activate the Relay 2 for 3 seconds by giving an impulse from the remote control			
		<i>Negative brake and Photocell 2 management</i>	The negative electric-brake is not active on the photocell intervention			
		<i>Negative brake 2 management</i>	Negative electric-brake <b>(in ON with the gate in cycle and 1 second before the Start input)</b>			
		<i>Positive brake 2 management</i>	Positive electric-brake <b>(in ON with stationary gate)</b>			
		<i>Opening electric-valve</i>	The relay 2 is active during opening			
		<i>Closing electric-valve</i>	The relay 2 is active during closing			
		<i>Clock 3 and 4</i>	The relay will be active in the same time band set on menus 126 e 127			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
134	RELAY FV 1 (Relay on the FV MODULE 1)	Off	Disabled	INVERTER	It depends on motor	
		Positive brake management	Positive electric-brake <b>(The relay FV1 will be ON only with stopped gate)</b>			
		Negative brake management	Negative electric-brake <b>(The relay FV1 will be ON only during operator cycle, 1 second before start and in case of photocell intervention )</b>			
		Negative brake management and Photocell	Negative electric-brake <b>(The relay FV1 will be ON only during operator cycle and 1 second before start, except in case of photocell intervention )</b>			
		Fan	The relay on FV MODULE will activate for the whole cycle duration plus 2 further minutes			
		Tail Gate	The Relay FV 1 will enable only if the gate is closed			
		Copy Start	The Relay FV 1 will enable at every START command			
135	RELAY FV 2 (Relay on the FV MODULE 2)	Off	Disabled	INVERTER	It depends on motor	
		Positive brake management	Positive electric-brake <b>(The relay FV2 will be ON only with stopped gate)</b>			
		Negative brake management	Negative electric-brake <b>(The relay FV2 will be ON only during operator cycle, 1 second before start and in case of photocell intervention)</b>			
		Negative brake management and Photocell	Negative electric-brake <b>(The relay FV2 will be ON only during operator cycle and 1 second before start, except in case of photocell intervention)</b>			
		Fan	The relay on FV MODULE will activate for the whole cycle duration plus 2 further minutes			
		Tail Gate	The Relay FV 2 will enable only if the gate is closed			
		Copy Start	The Relay FV 2 will enable at every START command			
136	EFO	0%      100%	<b>EFO function will be visible only with menu 3-MOTORS set on "5-Threephase/Bollards"</b> This function generates an emergency closing with a higher speed than the set percentage and without considering the safety devices connected. <b><u>It works only with BOLLARDS</u></b> and through a command on the PEDESTRIAN START input	INVERTER	50%	
137	COMIS	0      350 mA	It shows the absorption of the accessories connected on input 20 <b>(it only works if an accessory is connected at least)</b>	ALL	----	
138	COMIS THRESHOLD	Off      350mA	Allows to set a maximum absorption threshold over which an error message appears <b>(error message appears also when over 350 mA)</b>	ALL	Off	

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
<b>140</b>	THRESHOLD A OPENING 1	1      10 Ampere	Adjusts the amperometric intervention threshold of motor 1 in opening ( <b><i>over the set threshold motor will detect an obstacle</i></b> )	<b>INVERTER</b>	It depends on motor	
<b>141</b>	THRESHOLD A CLOSING 1	1      10 Ampere	Adjusts the amperometric intervention threshold of motor 1 in closing ( <b><i>over the set threshold motor will detect an obstacle</i></b> )	<b>INVERTER</b>	It depends on motor	
<b>142</b>	THRESHOLD A OPENING 2	1      10 Ampere	Adjusts the amperometric intervention threshold of motor 2 in opening ( <b><i>over the set threshold motor will detect an obstacle</i></b> )	<b>INVERTER</b>	It depends on motor	
<b>143</b>	THRESHOLD A CLOSING 2	1      10 Ampere	Adjusts the amperometric intervention threshold of motor 2 in closing ( <b><i>over the set threshold the motor will detect an obstacle</i></b> )	<b>INVERTER</b>	It depends on motor	
<b>144</b>	THRESHOLD A OPENING SLOWDOWN 1	1      10 Ampere	Adjusts the amperometric intervention threshold of motor 1 in slowdown during opening	<b>INVERTER</b>	It depends on motor	
<b>145</b>	THRESHOLD A CLOSING SLOWDOWN 1	1      10 Ampere	Adjusts the amperometric intervention threshold of motor 1 in slowdown during closing	<b>INVERTER</b>	It depends on motor	
<b>146</b>	THRESHOLD A OPENING SLOWDOWN 2	1      10 Ampere	Adjusts the amperometric intervention threshold of motor 2 in slowdown during opening	<b>INVERTER</b>	It depends on motor	
<b>147</b>	THRESHOLD A CLOSING SLOWDOWN 2	1      10 Ampere	Adjusts the amperometric intervention threshold of motor 2 in slowdown during closing	<b>INVERTER</b>	It depends on motor	
<b>190</b>	BASIC MENU	Press OK to exit the special menu. The special menu switches off automatically after 20 minutes				

**Note 1:** after initialization, the parameters set on menu **3 - MOTOR** and **104 - SELECT LIMIT SWITCH** always remain set to the value chosen during the programming operation

**Note 2:** if the menu **119 - DISPLAY WRITING SPEED** is set to the minimum value of 30%, the display writing speed will be low. On the contrary, if it is set to the maximum value of 100%, the writing speed will be very high

**Please note: the writing speed will not change on the JOLLY 3 programmer**





Automatic Gate Openers

International registered trademark n. 804888

**SEA S.p.A.**

**Zona Industriale Sant'Atto - 64020 - Teramo - ITALY**

**Tel. +39 0 861 588341 r.a. Fax +39 0 861 588344**

**[www.seateam.com](http://www.seateam.com)**